



K46SDM

Kawasaki Z650 2017-

Left side kit:

ID	Description	Cat.no	Pcs
1	SLDM adapter	537/B	1
2	Dural. cylinder	15	1
3	Bolt M10x110x1,25	928	1
4	Washer M6	1023	2
5	Bolt M6x20	1024	2

Right side kit:

ID	Description	Cat.no.	Pcs
1	SLDM adapter	537/B	1
2	Dural. cylinder	10	1
3	Bolt M10x170x1,25	903	1
4	Washer M6	1023	2
5	Bolt M6x20	1024	2

Instructions:

- 1.) Uscrew original bolt from the frame.
- 2.) Put SLD adapter and dural. cylinder on the bolt M10.
Note: on the right is longer bolt.
- 3.) Mount this kit on the frame of motorcycle.
- 4.) Mount slider on the SLD adapter using two bolts and washers M8.

We recommend to use the glue on all threads.

