

S3S

Suzuki SV650 N/S 2003-2006

Kit for left side:

ID.	Description	Cat.No	Qty
1	slider RDMoto	SL	1
2	Cap	SLcap..	1
3	Adapter for slider	DV-292	1
4	Adapter for moto	DV-182	1
5	Bolt M6x25	877	3
6	Bolt M4x16	876	2
7	Bolt M10x105x1,25mm	893	1

Kit for right side:

ID.	Description	Cat.No.	Qty
1	slider RDMoto	SL	1
2	Cap	SLcap..	1
3	Adapter for slider	DV-292	1
4	Adapter for moto	DV-181	1
5	Bolt M6x25	877	3
6	Bolt M4x16	876	2
7	Bolt M10x150x1,25mm	932	1

Instruction to assembly-left side:

1. Dismantel original bolt from frame.
2. Bolt ID.7 gripping the duralumin set ID.3,4.
3. Mount slider ID.1 and use bolts ID.5.
4. Insert ca pinto the slider ID.2 use bolts ID.6

Warning - we recommend use the glue of all threads - medium strong.

Instruction to assembly-right side:

1. Dismantel original bolt from frame.
2. Bolt ID.7 gripping the duralumin set ID.3,4.
3. Mount slider ID.1 and use bolts ID.5.
4. Insert ca pinto the slider ID.2 use bolts ID.6

Warning - we recommend use the glue of all threads - medium strong.

ILUSTRAČNÍ FOTO MÍSTA MONTÁŽE

