

S21-2

Suzuki GSX-R 600/750 2006-2007

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x75x1,25mm	938	1
3	Dural. cylinder d=10mm	423	1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x80x1,25mm	920	1
3	Dural. cylinder d=7mm	424	1

ILLUSTRATIVE PHOTOS OF PLACE OF THE INSTALLATION



You will have to drill the hole in the cowl during installation. It is therefore necessary intervention in the original cowl!



Installation:

Installation of the left and right protector make in gripping about the attached photo above. Give the steel box M10 (No. 1) on both bolts. Put the duralumin cylinder (No. 3) under the protector on the left side and use the bolt (No. 2) for tightening. Put the duralumin cylinder (No. 3) under the protector on the right side and use the bolt (No. 2) for tightening. At first finish the one side and then mount the second side.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).