

S37

Suzuki DL650/1000 V- Strom 2012-

Kit for left side:

No.	Description	Cat.no.	Pcs
1	Steel nut M12	X12/X2	1
2	Duralumin cylinder d=50mm	209	1
	Stainless steel bar M12x425x1,25mm		1

Kit for right side:

No.	Description	Cat.no.	Pcs
1	Steel nut M12	X12/X2	1
2	Duralumin cylinder d=50mm	209	1

Installation:

1. dismount the original bolt M12
2. insert steel bar M12x425x1,25mm throught the frame and engine
3. insert duralumin cylinder No. 2 into the frame
4. finally screw up all with nuts M12 (No. 1)

Warning - the threads of the screws is recommended to use premium adhesive moderate (blue color).

