

S42

Suzuki SV 650 2018-

Mounting Kit Left Side:

ID	Description	Cat.No.	Pcs
1	Dural. roller d=52,5	1309	1
2	Steel nut M12	X12/X2	1
3	Rod M12x430x1,25		1

Mounting Kit Right Side:

ID	Description	Cat. No.	Pcs.
1	Dural. roller d=52,5	1309	1
2	Steel nut M12	X12/X2	1





Mounting instructions for both sides:

1. Unscrew original M12 bolt going through the motorcycle frame.
2. Take the ID.3 M12 rod and push it through the frame. Then equip it with ID.1 roller, crash protector and M12 ID.2 steel nut from both sides.
3. Finally, tighten all bolts on both sides.

Note: We recommend using medium strenght thread glue during assembly (blue color).

