

Y40S

Yamaha MT-03 '14-

Fitting kit left side:

ID	Description	Cat.n	Qt
1	Bolt M6x25	877	3
2	Bolt M4x16	876	2
3	Dural.spacer d=48	1203	1
4	Bolt M10x125x1,25	924	1
5	Dural. adapter	292	1

Fitting kit right side:

ID	Description	Cat.n	Qt
1	Bolt M6x25	877	3
2	Bolt M4x16	876	2
3	Dural.spacer d=48	1203	1
4	Bolt M10x125x1,25	924	1
5	Dural. adapter	292	1

Instruction to assembly:

1. Remove original bolt from frame.

2. Left side:

3. Bolt ID.4 insert trough the dural.adapter ID.5.
4. Place dural spacer ID.3 on the bolt.
5. Place spacer ID.3 into the frame.
6. Assembly bolt with kit of adapters into the frame.
7. Take bolts ID.1 and mounting slider. Into the protector insert alu. cap and tighten it by bolts ID.2.
8. Take out off original bolt from frame.

9. Right side:

10. Bolt ID.4 insert trough the dural.adapter ID.5.
11. Place spacer ID.3 into the frame.
12. Assembly bolt with kit of adapters into the frame.
13. Take bolts ID.1 and mounting slider. Into the protector insert alu. cap and tighten it by bolts ID.2.



Use medium strong glue on all threads.