



# H39S

## Honda CB500 X/ CB500 F 2013-

### Kit for the left side:

ID	Description	Cat.No.	Quant.
1	Dural. adaper	646	1
2	Screw M10x75x1,25mm	938	1
3	Dural. roller - 20mm	435	1
4	Dural. adaptér pro slider-70mm	DV 315	1
5	Screw M10x55mm	1002	1
6	Washer M10	804	1
7	Screw M6x25mm	877	3
8	Screw M4x16mm	876	2
9	Imbus cover	X4	1
10	Nut M10	810	1

### Kit for the right side:

ID	Description	Cat.No.	pcs
1	Dural. adaper	647	1
2	Screw M10x75x1,25mm	938	1
3	Dural. roller - 20mm	435	1
4	Dural. adaptér pro slider-70mm	DV 315	1
5	Screw M10x55mm	1002	1
6	Washer M10	804	1
7	Screw M6x25mm	877	3
8	Screw M4x16mm	876	2
9	Imbus cover	X4	1
10	Nut M10	810	1

**Instruction:**

Mounting instructions for left and right side are same.



1. Remove original screw.
2. Fit dual adapter (ID1) on the frame of motorcycle using screw M10 (ID2). Insert roller (ID3) between frame and adapter.
3. Cover imbus with plastic cover.
4. Fit slider adapter (ID4) on dual adapter using screw M10 (ID5). Don't forget to use washer (ID6).
5. Fit slider on slider adapter using three screws M6 (ID7).
6. Fit Colored cover on slider using two screws M4 (ID8).

**Warning - the threads of the screws is recommended to use premium adhesive moderate (blue color).  
Rubber between the alloy. Adapters pull so to avoid its deformation.**

