



# A11SD

## Aprilia Caponord 1200 2013-

### Mounting Kit - Left Side:

ID	Description	Cat.No	Pcs
1	Moto adapter	32	1
2	Bolt M8x25	815	2
3	Washer	800	2
4	Nut M12	811	1
5	Dural. SLD carrier	537	1

### Mounting Kit - Right Side:

ID	Description	Cat.No	Pcs
1	Moto adapter	32	1
2	Bolt M8x25	815	2
3	Washer	800	2
4	Nut M12	811	1
5	Dural. SLD carrier	537	1

6	<b>Stainless steel rod 12(1,25)x430x30x30</b>	-	1
---	---	---	---

To connect the left and right sides, the mounting kit includes a stainless steel rod ID.6 with a length of 430 mm.

### Mounting instructions :

1. Remove original bolt M12 from the frame.
2. Insert the stainless steel rod ID.6 into the motorcycle frame.
3. Slide the adapters ID.1 on the left and right side.
4. Slide on the dural. SLD carrier ID.5 and tighten it with the nut ID.4 on each side.
5. Install the slider and secure it using the bolts ID.2 with the washer ID.3.

**Warning: We recommend using medium strength (blue) thread glue during assembly.**

