

BN3SD

Benelli BN600R 2013-

Fitting kit right side:

ID	Description	Cat.N	QTY
1	Bolt M10x110	879	1
2	Washer M10 spring	801	1
3	Dural. adapter	149	1
4	Bracket for SLD	537	1
5	Bolt M8	815	2
6	Washer M8 spring	800	2
7	Dural. cylinder 20mm	DV2	1

Fitting kit left side:

ID	Description	Cat.N	QTY
1	Bolt M10x85	981	1
2	Washer M10 spring	801	1
3	Dural. adapter	149	1
4	Bracket for SLD	537	1
5	Bolt M8	815	2
6	Washer M8 spring	800	2





Fitting kit left side:

1. Dismantle original bolt from frame.
2. Take bolt ID.1. Insert washer ID.2 and bracket ID.4 on the bolt.
3. Insert dural. adapter ID.3 and under the adapter put dural.cylinder. ID.7.
4. This set, mount into the frame. Original dural. cylinder leave in frame.
5. Use bolts ID.5 and washers ID.6 for gripping the slider.

Fitting kit right side:

1. Dismantle original bolt from frame.
2. Take bolt ID.1. Insert washer ID.2 and bracket ID.4 on the bolt.
3. Insert dural. adapter ID.3.
4. This set, mount into the frame. Original dural. cylinder leave in frame.
5. Use bolts ID.5 and washers ID.6 for gripping the slider.

Warning: Use glue of all threads. Medium strong.