

BN7

Benelli Leoncino Naked '17-

Kit for right side

ID.	Description	Cat. No.	Pcs.
1	Dural. roller d=50mm	DV5	1
2	Steel housing	X1	1
3	Bolt M10x170	935	1
4	Washer M10	804	1
5	Safety Nut M10	810	1

Kit for left side

ID.	Description	Cat. No.	Pcs.
1	Dural. roller d=20mm	DV2	1
2	Steel housing	X1	1
3	Bolt M10x170	935	1
4	Washer M10	804	1
5	Safety nut M10	810	1

Mounting Instructions:

1. Proceed with mounting of the crash protector into motorcycle frame as shown on attached pictures.
2. Insert the ID.2 housing into the protector. Then, insert into it the ID.3 bolt and onto the bolt put the ID.1 roller. Take this assembly and mount it into the motorcycle frame.
3. Now proceed with the same steps on the other side.

Note – We recommend using medium strength glue for threads of all screws during assembly.



