

D1(10)S

Ducati Monster 600/750/900 (-2000)

ID.	Description	Cat.no.	pcs
1	Steel rod M10x(1,25)x375x30x30	-	1
2	Slider adapter	317	2
3	Special nut M10x1,25	X11	2
4	Dural cylinder d=46mm	25	1
5	Dural cylinder d=48mm	26	1
6	Bolt M6x25	877	6
7	Bolt M4x16	876	4

Instructions:

- 1.) Remove original bolts from frame.
- 2.) Insert steel rod into the frame.
- 3.) Put dural cylinders on the rod from both sides.
- 4.) After dural cylinders put slider adapter.
- 5.) Tighten this set using special nuts.
- 6.) Now fit slider on the slider adapter using three M6 bolts.
- 7.) In the end fit coloured cover using two M4 bolts.

