

H5SD

Honda CBF600 2008- Honda CB600F Hornet 2007-

Kit for left side:

ID	Description	Cat.No	Qty
1	Slider SLD	SLD	1
2	Bolt M8x25	815	2
3	Washer M8	802	2
4	Bolt M10x40	854	1
5	Dural. adapter for SLD	DV-10	1
6	Dural. adapter	609	1
7	Bolt M12x85x1,25mm	899	1
8	Bolt M10x65x1,25mm	945	1
9	dural.cylinder d=12mm	80	1
10	dural.cylinder d=8mm	79	1
11	Washer M10-spring	801	1
12	Dural.bracket for SLD	537	1

Kit for right side:

ID	Description	Cat.No	Qty
1	Slider SLD	SLD	1
2	Bolt M8x25	815	2
3	Washer M8	802	2
4	Bolt M10x40	854	1
5	Dural. adapter for SLD	DV-10	1
6	Dural. adapter	610	1
7	Bolt M12x65x1,25mm	940	1
8	Bolt M10x65x1,25mm	945	1
9	dural.cylinder d=12mm	80	1
10	Washer M10-spring	801	1
11	Dural.bracket for SLD	537	1

Instruction to assembly-left side:

1. Take out originals bolt from frame.
2. Insert bolts ID.7 and ID.8 into the dural.adapter ID.6.
3. Put on the bolts dural.cylinder ID.9 and ID.10, and mount this set on the frame, use the original bolt and washer.
4. Take bolt ID.4 put on the bolt washer M10 ID.11, dural.bracket for SLD ID.12 and dural.adapter for SLD ID.5
5. This kit mount on the frame.
6. Use bolts and washer ID.2 a ID.3 and mount DIAMOND.

Instruction to assembly-right right side:

1. Take out originals bolt from frame.
2. Insert bolts ID.7 and ID.8 into the dural.adapter ID.6.
3. Put on the bolts dural.cylinder ID.9 from back side the dural. holder.
4. Mount this kit on the frame.
5. Take bolt ID.4 put on the bolt washer M10 ID.10, dural.bracket for SLD ID.11 and dural.adapter for SLD ID.5
6. This kit mount on the frame.
Use bolts and washer ID.2 a ID.3 and mount DIAMOND

Warning – use the glue of all threads. Medium strong.

