

H5-2S

Honda CBF600 2008- Honda CB600F Hornet 2007-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Slider RDMoto	SL	1
2	Cover	SLcap..	1
3	Adapter moto	DV-314	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Bolt M12x80x1,25mm	908	1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Slider RDMoto	SL	1
2	Cover	SLcap..	1
3	Adapter moto	DV-314	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Bolt M12x70x1,25mm	937	1

Installation – the left side:

1. remove the original bolt
2. use the bolt (No. 6) for gripping of duralumin cylinder (No. 3), you have to mount adapter with thread M6 up, then slider have the right rotation.
3. put slider (No. 1) and use the bolts (No. 4) for mounting
4. insert in slider the cover (No. 2) and use the bolts (No. 5) for gripping

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

Installation – the right side:

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

1. remove the original bolt
2. use the bolt (No. 6) for gripping of duralumin cylinder (No. 3), you have to mount adapter with thread M6 up, then slider have the right rotation.
3. put slider (No. 1) and use the bolts (No. 4) for mounting
4. insert in slider the cover (No. 2) and use the bolts (No. 5) for gripping

