

H10-2*

Honda CBR600RR 2003-2006

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M12	X2	1
2	Bolt M12x120x1,25mm	913	1
3	Dural. cylinder d=38mm	98	1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M12	X2	1
2	Bolt M12x110x1,25mm	910	1
3	Dural. cylinder d=34mm	99	1

Installation:

***You will have to drill the hole in the cowl during installation. It is therefore necessary intervention in the original cowl!**

1. Measure and make hole into the fairing.
2. Installation of the left and right protector make in gripping about the attached photo .
3. Give the steel box M12 ID.1 into the protectors.
4. Put the duralumin spacer ID.3 length 38mm left side under the crash protector and insert bolt M12x120 into the protector and spacer- left side.
5. For right side use bolt M12x110 and spacer length 34mm.
6. These kits fitting into the chassi.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).



