

# H12S

## Honda CBR929/954RR 2000-2003

### Kit for the left side

| ID. | Description        | Cat.no  | Pcs |
|-----|--------------------|---------|-----|
| 1   | slider RDMoto      | SL      | 1   |
| 2   | Cover              | SLcap.. | 1   |
| 3   | Moto adapter       | DV-310  | 1   |
| 4   | Bolt M6x25         | 877     | 3   |
| 5   | Bolt M4x16         | 876     | 2   |
| 6   | Bolt M10x70x1,25mm | 898     | 1   |

### Kit for the right side

| ID | Description        | Cat.no. | Pcs |
|----|--------------------|---------|-----|
| 1  | slider RDMoto      | SL      | 1   |
| 2  | Cover              | SLcap.. | 1   |
| 3  | Moto adapter       | DV-309  | 1   |
| 4  | Bolt M6x25         | 877     | 3   |
| 5  | Bolt M4x16         | 876     | 2   |
| 6  | Bolt M10x70x1,25mm | 898     | 1   |



### Instructions:

1. Remove original bolt from the frame of motorcycle.
2. Using bolt M10 (ID6) fit dural adapter (ID3). Set rotation before tightening.
3. Place slider (ID1) on the dural adapter and tighten it using bolts (ID4)
4. Place cover (ID2) into the slider and tighten it using bolts (ID5).

**We recommend to use the safety glue on all threads (medium strong).**

Illustrative photos

