

H22SD

Honda CB1000R Hornet 2008-2011

Fitting kit:

ID.	Description	Cat.N	Qt
1	Slider holder	537	2
2	Spacer d=15mm	DV-149	2
3	Bolt M12x95x1,25	900	2
4	Bolt M8x25	815	4
5	Washer	802	4

Assembly instruction are same for both sides.

1. Dismantle original bolts M12 from chassi.
2. Insert bolt ID.3 into the slider holder and spacer. Fix it into the engine thread.
3. Place slide rand fix it by bolts + washers M8.

Note: We recommend use medium strong glue to all threads.

