

K26-2SDM

Kawasaki ZX250R-Ninja 2008-

Kit for the left side

ID	Description	Cat.no.	Pcs
1	SLDM adapter	537/B	1
2	Bolt M10x40mm	854	1
3	Steel adapter	626	1
4	Poly cylinder 150mm	463	1
5	Bolt M10x30mm	888	1
6	Bolt M8x25mm	831	1
7	Washer M10	801	1
8	Cylinder 15mm	DV9	1
9	Bolt M6x20	1024	2
10	Washer M6	1023	2
11	Tape 3M		1
12	Dural.bar AL16(M8)x209x30x30		1

Kit for the right side

ID	Description	Cat.no.	Pcs
1	SLDM adapter	537/B	1
2	Bolt M10x40mm	854	1
3	Steel adapter	627	1
4	Poly cylinder 150mm	463	1
5	Bolt M10x30mm	888	1
6	Bolt M8x25mm	831	1
7	Washer M10	801	1
8	Cylinder 15mm	DV9	1
9	Bolt M6x20	1024	2
10	Washer M6	1023	2
11	Tape 3M		1



INSTRUCTIONS

- 1) Dismantle side fairing.
- 2) Fit cylinders ID4 on steel adapters ID3 using bolts ID5. Fit this kit on the frame of motorcycle using original bolts.
- 3) Connect both adapters using dural. bar ID12 and bolts ID6.
- 4) Mount fairing back on the bike.
- 5) Put bolt ID2 through washer ID7, SLD adapter ID1 and cylinder ID8. Mount this kit into the cylinder on the bike.
- 6) In the end fit slider using two bolts and washers (ID9 and ID10).

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

