



K30S

Kawasaki ER-6N 2012-

Kit for left side:

ID	Description	Cat.No	QTY
1	Bolt M10x40	854	1
2	Dural. cylinder 10mm	1	1
3	Steel bracket for SL01	649	1
4	Nut M10	810	1
5	Washer M10	804	1
6	Dural. adapter for SL01	DV318	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

Kit for right side:

ID	Description	Cat.No	QTY
1	Bolt M10x40	854	1
2	Dural. cylinder 10mm	1	1
3	Steel bracket for SL01	648	1
4	Nut M10	810	1
5	Washer M10	804	1
6	Dural. adapter for SL01	DV318	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

Instruction to assemble:

Left side:

1. Dismantle original bolt from frame.
2. Mounting steel bracket ID.3, used original bolt, the cylinder on the bracket must fixed on the frame.
3. Through the dural. adapter(ID6) and dural. cylinder (ID2) insert bolt M10x40 (ID1).
4. This set mount on the bracket. Used washer M10 (ID5) and nut M10 (ID4).
5. Fixed slider SL01 by bolt (ID7).
6. Into the slider insert cover and fixed by bolt M4 (ID8).

Right side:

1. Dismantle original bolt from frame.
2. Mounting steel bracket (ID3), used original bolt, the cylinder on the bracket must fixed on the frame.
3. Through the dural. adapter(ID6) and dural. cylinder (ID2) insert bolt M10x40 (ID1).
4. This set mount on the bracket. Used washer M10 (ID5) and nut M10 (ID4).
5. Fixed slider SL01 by bolt (ID7).
6. Into the slider insert cover and fixed by bolt M4 (ID8).

Warning – used the glue on the all threads.

