

S16

Suzuki GSX 600/750F '98-

Fitting kit:

ID	Description	Cat.N	Qt
1	Steel sleeve M10	X1	2
2	Bolt M8x30	834	4
3	Bolt M10x35	847	2
4	Washer M8	802	4
5	Tape 3M	-	2
6	Steel adapter	562	1
7	Steel adapter	563	1

Assembly instruction:

1. Plac for fitting you see on the pictures.
2. Grip steel adapters for left and right side by bolts ID.2 and use washers ID.4.
3. Insert steel sleeves ID.1 into the crash protectors.
4. And fix protectors by bolts ID.2 on the steel adapters.

Note: We recomande to use medium strong glue during assembly on the threads.

