

S26

Suzuki GSX-650F 2008-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M8x30mm	834	2
3	Dural. cylinder d=70mm	7	1
4	Bolt M10x120mm	881	1
5	Pad M8 (spring)	800	2
6	Steel adapter	565	1
7	Tape 3M		1
8	Dural. bar AL16(M10)x435x30x30		1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x55x1,25mm	915	2
3	Dural. cylinder d=10mm	1	1
4	Dural. cylinder d=10mm	111	2
5	Bolt M10x60mm	850	1
6	Pad M10 (spring)	801	2
7	Steel adapter	564	1
8	Tape 3M		1

Installation:

1. remove the complete side cowl and the bolts in the place of the gripping of steel adapters
2. use the tape 3M during the installation of the steel adapters for the defining the place between the adapter and the frame of the motorcycle
3. mount the steel adapters on the left and right side of the frame of the motorcycle according to the below attached pictures
4. take the right adapter and give the bolt (No. 2) together with the pad (No. 6) into the adapter, the other side of the adapter give the duralumin cylinders (No. 4) on the bolts, screw up the adapter lightly
5. use the bolt (No. 2) together with the pads (No. 5) for the gripping of the left adapter, screw up lightly
6. give the steel box (No. 1) together with bolt (No. 4) into the protector, give the duralumin cylinder (No. 3) under the protector, the cylinder give on bolt too
7. all this set put through the steel adapter and mount into the duralumin bar (No. 8, AL5)
8. do installation on the other side the same
9. check all and screw up



Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

