

CF61

Honda CBF500

Kit for the left side

ID	Description	Cat.no.	Pcs
1	Cylinder	DV435	1
2	Nut M10	810	3
3	Washer M10 flat	804	3
4	Steel rod 10x225x30x30		1
5	Steel rod 10x240x30x30		1
6	Steel rod 10x335x30x30		1
7	Nut cover	X35	1

Kit for the right side

ID	Description	Cat.no.	pcs
-	-	-	-
2	Nut M10	810	3
3	Washer M10 flat	804	3
-	-	-	-
-	-	-	-
-	-	-	-
7	Nut cover	X35	1

Instructions:

- 1.) Remove original bolts from motorcycle according to the pictures.
- 2.) Insert all steel rods through motorcycle.
 - a. ID4 – rear upper.
 - b. ID5 – rear lower (cylinder ID1 on the left).
 - c. ID6 – front.
- 3.) Put crash frames on rods and tighten whole kit using M10 nut ID2. Don't forget to place washers ID3 under nuts.
- 4.) Cover front nuts using nut cover ID7.



