

S40S

Suzuki GSX-S1000 '16-

Left side:

ID	Description	Cat.	Qt
1	Alu.spacer d=30mm	353	1
2	Bolt M10x60x1,25	896	1
3	Bolt M6x25	877	3
4	Bolt M4x12	876	2

Right side:

ID	Description	Cat.	Qt
1	Alu. spacer d=31,5	354	1
2	Bolt M10x70x1,25	898	1
3	Bolt M6x25	877	3
4	Bolt M4x12	876	2

Assembly:

1. Dismantle bolts M10 from chassi.
2. Insert bolts ID.2 into the alu. spacers.
3. These kits assembly from left and right side chassi. For left side use shorter bolt and spacer.
4. Place sliders on the spacers and fix it by bolts ID.3.
5. Insert alu. cover and fix it by bolts ID.4.

Note: Use gule of all threads during assembly.

