



# Y10

## Yamaha FZS1000 Fazer 2001-2005

### Kit for the left side

No.	Description	Cat.no	Pcs
1	Steel box M12	X2	1
2	Bolt M12x40mm	857	1
3	Bolt M10x130mm	883	1
4	Bolt M8x130mm	884	1
5	Pad M10 (plane)	804	1
6	Nut M10 (safety)	810	1
7	Pad M8 (plane)	802	1
8	Nut M8 (safety)	809	1
9	Duralumin adapter	586	1

### Kit for the right side

No.	Description	Cat.no	Pcs
1	Steel box M12	X2	1
2	Bolt M12x40mm	857	1
3	Bolt M10x130mm	883	1
4	Bolt M8x130mm	884	1
5	Pad M10 (plane)	804	1
6	Nut M10 (safety)	810	1
7	Pad M8 (plane)	802	1
8	Nut M8 (safety)	809	1
9	Duralumin adapter	586	1

### Installation – the left side:

1. remove the original bolt M10 and M8, which are on frame before the engine
2. installation of adapter on motorcycle is not difficult. At first give the bolt (No. 3) with pad (No. 5) and bolts (No. 4) with pad (No. 7) in adapter.
3. give adapter on motorcycle and use nuts (No. 6) and (No. 8) for tightening on reverse side.
4. put steel box (No. 1) together with bolt (No. 2) in protector
5. all this set mount to thread on adapter

**Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**

### **Installation – the right side:**

1. remove the original bolt M10 and M8, which are on frame before the engine
2. installation of adapter on motorcycle is not difficult. At first give the bolt (No. 3) with pad (No. 5) and bolts (No. 4) whit pad (No. 7) in adapter.
3. give adapter on motorcycle and use nuts (No. 6) and (No. 8) for tightening on reverse side.
4. put steel box (No. 1) together with bolt (No. 2) in protector
5. all this set mount to thread on adapter

**Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**

