

# Y18

## Yamaha YZF-R1 2000-2001

### Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel insert	X1	1
2	Bolt M10x100x1,25mm	892	1
3	Dural cylinder 41mm	165	1

### Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel insert	X1	1
2	Bolt M10x100x1,25mm	892	1
3	Dural cylinder 30mm	3	1

### Installation:

Installation of the left and right protector make in gripping about the attached photo above. Give the steel box M10 (No. 1) on both bolts. Put the duralumin cylinder (No. 3) under the protector on the left side and use the bolt (No. 2) for tightening. Put the duralumin cylinder (No. 3) under the protector on the right side and use the bolt (No. 2) for tightening. At first finish the one side and then mount the second side.

**Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).**

