



Y24

Yamaha FJR1300 2006-2012

Kit for right side:

No.	Description	Cat.no.	Quant.
2	Steel box	X2	1
3	Duralumin cylinder d=15mm	93	1
4	Bolt M12x95	900	1

Kit for left side:

No.	Description	Cat.no.	Quant.
2	Steel box	X2	1
3	Duralumin cylinder d=25mm	94	1
4	Bolt M12x105mm	912	1

Installation – the right side:

1. remove the original bolt
2. insert steel box (no.2) to the protector
3. into the frame insert duralumin cylinder (no.3)
4. through the protector insert bolt (no.4) and mounting on the motorcycle frame

Installation – the left side:

1. remove the original bolt
2. insert steel box (no.2) to the protector
3. into the frame insert duralumin cylinder (no.3)
4. through the protector insert bolt (no.4) and mounting on the motorcycle frame

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

Ilustation picture, aprox. place for protector gripping.

