

Y33SDM

Yamaha MT07 2014

Kit for leesft side:

ID	Description	Cat.no	QTY
2	Dural. Cylinder	1115	1
3	Bracket for SLD	537	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2
6	Bolt M12x110x1,25	910	1

Kit for right side:

ID	Description	Cat.no	QTY
2	Dural. Cylinder	1115	1
3	Bracket for SLD	537	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2
6	Bolt M12x110x1,25	910	1

Instruction to assemble left side:

1. Dismantle original bolt from frame.
2. Insert duralumin cylinder ID2 into the frame.
3. On the dural. Cylinder assemble bracket for SLD (ID3) use the bolt (ID6).
4. Mounting slider (ID1) use the bolt (ID4) amd washer (ID5).

Instruction to assemble right side:

5. Dismantle original bolt from frame.
6. Insert duralumin cylinder ID2 into the frame.
7. On the dural. Cylinder assemble bracket for SLD (ID3) use the bolt (ID6).
8. Mounting slider (ID1) use the bolt (ID4) amd washer (ID5).

Use the glue on the all threads.

