

Y36S

Yamaha R1 2015

Kit for left side:

ID	Description	Cat.N	QTY
1	Alu. spacer for SL	348	1
2	Bolt 12x95x1,25	900	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2

Kit for right side:

ID	Description	Cat.N	QTY
1	Alu. spacer for SL	1137	1
2	Bolt M12x60x1,25	916	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2
5	Alu. Roller d=5mm	1260	1

Instruction to assembly:

1. The first do assembly left side.
2. Take off Original bolt.
3. Leave all spacer's/bushes in place.
4. Take the alu. spacer ID.1 for **left side**, insert bolt ID.2 into the spacer ID.1.
5. This kit gripping on the frame and tighten.
6. Place slide and tighten it by bolts ID.3, place alu. cover into the slider use bolts ID.4.
7. **Mounting instruction for right side.**
8. Take off Original bolt.
9. Please leave all spacer's/bushes in place.
10. Take the alu. spacer ID.1 for **right side** insert bolt ID.2 into this kit.
11. This kit gripping on the frame and tighten.
12. Place slide and tighten it by bolts ID.3, place alu. cover into the slider use bolts ID.4.

Warning: We recommend use the glue of all threads. Medium strong.



