

# B9-2S

## BMW F800R 2014-

### Kit for the left side:

ID.	Description	Cat.no.	pcs
1	Adapter moto	DV-316	1
2	Bolt M6x25	877	3
3	Bolt M4x16	876	2
4	Bolt M10x90mm	880	1
5	Washer M10- perova	801	1

### Kit for the right side:

ID.	Description	Cat.no.	pcs
1	Adapter moto	DV-316	1
2	Bolt M6x25	877	3
3	Bolt M4x16	876	2
4	Bolt M10x90mm	880	1
5	Washer M10 - pérová	801	1
6	Dural spacer d=6mm	453	1



### Installation – left side:

1. Remove original bolt from the frame of motorcycle.
2. Insert bolt+washer (ID4+ID5) into dural adapter (ID1)
3. Mount this kit on the frame of motorcycle.
4. Fit slider using bolts (ID2). Fit coloured cover on the slider using bolts (ID3)

### Installation – right side:

1. Remove original bolt from the frame of motorcycle.
2. Insert bolt+washer (ID4+ID5) into dural adapter (ID1)
3. Insert dural spacer (ID6) into the frame.
4. Mount this kit on the frame of motorcycle.
5. Fit slider using bolts (ID2). Fit coloured cover on the slider using bolts (ID3)

**We recommend to use the glue on all threads (medium strong – blue colour).**