

B6-SL02

BMW S1000RR HP4

Kit for the left side:

| ID. | Description | Cat.no. | Pcs |
|-----|-------------------------|---------|-----|
| 1 | Steel adapter | 672 | 1 |
| 2 | Dural. Reduction-longer | 343 | 1 |
| 3 | Bolt M10x65 | 943 | 2 |
| 4 | Washer M10 | 804 | 2 |
| 5 | Alu. cylinder 6,7mm | 1105 | 2 |
| 6 | 3M Tape | 3M | 1 |
| 7 | Bolt M10x90 | 880 | 1 |
| 8 | Crash protector SL02 | | 1 |

Kit for the right side:

| ID. | Description | Cat.no. | pcs |
|-----|-------------------------|---------|-----|
| 1 | Steel adapter | 673 | 1 |
| 2 | Dural reduction-shorter | 342 | 1 |
| 3 | Bolt M10x60 | 973 | 2 |
| 4 | Alu. cylinder 7,2mm | 1107 | 2 |
| 5 | 3M Tape | 3M | 1 |
| 6 | Bolt M10x65 | 943 | 1 |
| 7 | Crash protector SL02 | | 1 |

Mounting instructions (left side):

1. Remove fairing of motorcycle.
2. Remove original bolts from frame.
3. Place alu cylinders (ID5) under steel adapter (ID1).
4. Fit steel adapter using M10 bolts (ID3). Don't forget to place alu cylinders (ID5) under bolts.
5. Place 3M tape on the frame (ID6).
6. **Mount fairing back on the motorcycle.**
7. Insert bolt M10x90 (ID7) into the protector and dural reduction (ID2).
8. Mount this kit on the steel adapter.
9. In the end mount coloured covers into protectors.

Mounting instructions (right side):

1. Remove fairing of motorcycle.
2. Remove original bolts from frame.
3. Place alu cylinders (ID4) under steel adapter (ID1).
4. Fit steel adapter using M10 bolts (ID3). Don't forget to place alu cylinders (ID5) under bolts.
5. Place 3M tape on the frame (ID5).
6. **Mount fairing back on the motorcycle.**
7. Insert bolt M10x90 (ID6) into the protector and dural reduction (ID2).
8. Mount this kit on the steel adapter.
9. In the end mount coloured covers into protectors.

We recommend to use the glue on all threads (medium strong).

