

K49

Kawasaki Z900RS 2018-

Kit for the left side

ID.	Description	Cat.no.	Pcs
1	Steel insert M10	X1	1
2	Bolt M10x130x1,25mm	905	1
3	Dural cylinder 68mm	145	1

Kit for the right side

ID	Description	Cat.no.	Pcs
1	Steel insert M10	X1	1
2	Bolt M10x130x1,25mm	905	1
3	Dural cylinder 68mm	145	1





Instructions:

- 1.) Put steel inser, protector and dural. cylinder on bolt ID1.
- 2.) Fit this kit into on the frame of motorcycle.

We recommend to use safety glue on all threads (medium strong).