



RDMOTO CZECH REPUBLIC  
info@rdmoto.cz  
www.rdmoto.cz

# S24SD

## Suzuki GSX-R1300 Hayabusa 2008-

### Kit for the left side

ID.	Description	Cat.no.	pcs
1	Slider diamond RDmoto	SLD	1
2	Dural.adapter (cylinder)	DV149	1
3	Washer M8	802	2
4	Bolt M8x25	815	2
5	Slider adapter	537	1
6	Bolt M10x70x1,25mm	898	1
7	Dural. cylinder - 80mm	142	1
8	Bolt M8x25mm	831	1
9	Bolt M12x120mm	968	1
10	Washer M10 (stringed)	801	1
11	Steel adapter	571	1
12	Tape 3M		1
13	Dural. cylinder d=15mm	109	1
14	Dural. rod AL16(M8)x358x30x30		1

### Kit for the right side

ID.	Description	Cat.no.	pcs
1	Slider diamond RDmoto	SLD	1
2	Dural.adapter (cylinder)	DV149	1
3	Washer M8	802	2
4	Bolt M8x25	815	2
5	Slider adapter	537	1
6	Bolt M10x60x1,25mm	896	1
7	Dural. cylinder - 90mm	143	1
8	Bolt M8x25mm	831	1
9	Bolt M12x130mm	886	1
10	Washer M10 (stringed)	801	1
11	Steel adapeter	572	1
12	Tape 3M		1
13	Bolt M8x40mm	828	1
14	Washer M8 (stringed)	800	1

### Instructions:

- 1. We recommend to use the glue on all threds (blue color – medium strong).**
2. Remove fairing of motorcycle.
3. Remove original bolts M10 from both sides and one bolt M8 from the right side of motorcycle.
4. Stick tape 3M between adapter and frame of motorcycle.
5. Fit steel adapters on the frame of motorcycle. Tighten it using bolts (ID6) and (ID13 – only right side). Add dural. cylinder (ID13) on the left side. Do not forget to place washers.
6. Insert dural. rod between adapters and tighten it using botls (ID8)
7. Put fairing back.
8. In the end fit slider.
  - a. Prepare bolt (ID9) and put slider adapter (ID5), dural. adapter (cylinder – ID2),and dural cylinder (ID7) on it.
  - b. Fit this kit on the steel adapter.
  - c. Fit protector (ID1) on the slider adapter (ID5) using two bolts and washers (ID5 + ID3).

