



T4

Triumph Street Triple 675 2007- Triumph Street Triple 675R 2009-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Duralumin adapter	613	1
2	Bolt M10x35mm	847	1
3	Bolt M10x120x1,25mm	895	1
4	Bolt M10x60x1,25mm	896	1
5	Dural. cylinder d=40mm	71	1
6	Steel box M10	X1	1
7	Plastic cover M10	X4	2

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Duralumin adapter	614	1
2	Bolt M10x35mm	847	1
3	Bolt M10x110x1,25mm	928	1
4	Bolt M10x60x1,25mm	896	1
5	Dural. cylinder d=32,5mm	68	1
6	Steel box M10	X1	1
7	Plastic cover M10	X4	2

Installation – the left side:

1. use the bolt (No. 3) and the bolt (No. 4) for mounting of the duralumin adapter (No. 1), give the duralumin cylinder (No. 5) on the bolt (No. 3) during the installation
2. if you mounted duralumin adapters, you can mount the crash protector. Give the steel box (No. 6) and the crash protector on the bolt (No. 2).
3. all this set mount on the duralumin adapter
4. give the plastic covers (No. 7) on the head of bolt

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).



Installation – the right side:

1. use the bolt (No. 3) and the bolt (No. 4) for mounting of the duralumin adapter (No. 1), give the duralumin cylinder (No. 5) on the bolt (No. 3) during the installation
2. if you mounted duralumin adapters, you can mount the crash protector. Give the steel box (No. 6) and the crash protector on the bolt (No. 2).
3. all this set mount on the duralumin adapter
4. give the plastic covers (No. 7) on the head of bolt

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

