

CF67

Lower

Honda CRF 1000 Africa Twin DCT '16-

Fitting kit:

ID	Description	Cat.N	Qt
1	Spacer l=5, hole dia. 8,5	433	1
2	Spacer l=17, hole dia. 8,5	1190	1
3	Bolt M8x130	884	1
4	Washer M8 flat	802	2
5	Nut M8 safety	809	1
6	Silentblock	X34	1

Note: Use medium strong glue during assembly on the all threads.




Remove original bolt M8 from the frame of motorcycle.

Left side:

Put washer ID.4 on bolt. Now mount crash bar with spacer l=17mm on the motorcycle.

Right side:

Fit silentblock on the crash bar. Prepare spacer l=5mm, crash bar, washer and fit it on the right side using nut ID5.



Use original bolts for tightening frame.