

Y41S

Yamaha MT-10 2016-

Kit for left side:

ID	Description	Cat.N	QTY
1	Alu. spacer for SL	358	1
2	Bolt 12x90x1,25	931	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2

Kit for right side:

ID	Description	Cat.N	QTY
1	Alu. spacer for SL	359	1
3	Bolt M12x60x1,25	940	1
4	Bolt M6x25	877	3
5	Bolt M4x16	876	2
6	Alu. Roller d=4mm	1260	1

Instructions:

1. Left side.

- Remove original bolt from the left side.
- Leave all spacers in the frame.
- Take the alu. spacer ID.1 for **left side**, insert bolt ID.2 into the spacer ID.1.
- This kit fit on the frame and tighten.
- Place slide and tighten it by bolts ID.3, place alu. cover into the slider use bolts ID.4.

2. Right side.

- Take off Original bolt.
- Leave all spacers in frame.
- Take the alu. spacer ID.1 for **right side**. Insert bolt ID.3 into this kit.
- Fit this kit on the frame and tighten.
- Place slider and tighten it by bolts ID.4, place alu. cover into the slider using bolts ID.5.

Warning: We recommend use the glue of all threads. Medium strong.



