



# KTM4S

## KTM 390 Duke 2013-17'

### Kit for right side:

ID.	Description	Cat.N	Qt
1	Dural.adapter for SL01	315	1
2	Dural. cylinder d=13mm	464	1
3	Dural. cylinder d=15mm	465	1
4	Bolt M10x45	847	1
5	Bolt M8x45mm	964	2
6	Steel adapter	628	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

### Kit for left side:

ID.	Description	Cat.N	Qt
1	Dural.adapter for SL01	315	1
2	Dural. cylinder d=17mm	1190	1
3	Dural. cylinder d=17mm	1190	1
4	Bolt M10x45	847	1
5	Bolt M8x45mm	964	2
6	Steel adapter	628	1
7	Bolt M6x25	877	3
8	Bolt M4x16	876	2

### Instruction to assembly:

1. Instruction to assembly for left and right hand side are same.
2. Do the mounting left side first.
3. Take out original bolts M8 from frame.
4. Insert duralumin cylinders into the frame (ID.2 is UP and ID.3 is down).
5. Take bolts ID.6 and gripping steel adapter ID.6 on the bike.
6. Bolt ID.4 insert into the dural.adapter ID.1.
7. Do mounting this kit on the motorcycle frame. (see photo).
8. By bolts ID.7 gripping slider. Put alu. cover into the slider, use bolts ID.8.

**Warning - on the threads of all bolts recommend the use of medium strong glue for threads (blue).**

