

K52

Kawasaki ZX-6R 636 2019-

Kit for left side

Kit for right side

Pos.	Description	Cat.No.	Pcs	Pos.	Description	Cat.No.	Pcs
1	AL insert M10	X1	1	1	AL insert M10	X1	1
2	bolt M10x105x1,25mm	893	1	2	bolt M10x110x1,25mm	928	1
3	dural. cylinder length=35mm	1341	1	3	dural. cylinder length=30mm	1342	1

Installation :

Installation of the left and right protector make in gripping about the attached photo above. Give the AL box M10 (No. 1) on both bolts. Put the duralumin cylinder (No. 3) under the protector on the left side and use the bolt (No. 2) for tightening. Put the duralumin cylinder (No. 3) under the protector on the right side and use the bolt (No. 2) for tightening. At first finish the one side and then mount the second side.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

