



V1

VOGE 300AC

Kit for left side

ID.	Description	Cat.No	Pcs
1	Steel nut M10	X11	1
2	Aluminum protector insert	X1	1
3	Dural. roller l=30mm	3	1
4	Steel rod 10x410(1,25)x30x30		1

Kit for right side

ID.	Description	Cat.No	Pcs
1	Steel nut M10	X11	1
2	Aluminum protector insert	X1	1
3	Dural. roller l=30mm	3	1

Instruction :

1. Remove the original M10 bolt from the motorcycle frame.
2. Insert the steel rod M10x410x1.25mm ID.4 through the motorcycle frame.
3. Place ID.3 duralumin rollers on both ends.
4. Insert the AL insert ID.2 into the protector and tighten the protectors with the ID.1 nuts.

Note: We recommend using medium strenght thread glue for all bolts (blue color).