

H68S

Honda CB750 Hornet 2022-

Kit for left side :

ID	Description	Cat.No.	Pcs
1	AL. frame adapter	770	1
2	Bolt M10x80mm	852	2
3	Nut M10-pojistná	810	2
4	Plastic cover	X4	2
5	Dural.roller under slider	318	1
6	Bolt M10x35mm	847	1
7	Bolt M6x25mm	877	3
8	Bolt M4x12mm	876	2

Kit for right side :

ID	Description	Cat.No.	Pcs
1	AL. frame adapter	770	1
2	Bolt M10x80mm	852	2
3	Nut M10-pojistná	810	2
4	Plastic cover	X4	2
5	Dural.roller under slider	318	1
6	Bolt M10x35mm	847	1
7	Bolt M6x25mm	877	3
8	Bolt M4x12mm	876	2

Installation :

The assembly procedure of the left and right sides is the same.

1. Remove the original screws from the motorcycle frame on one side (see picture).
2. Take the duralumin adapter ID.1 and insert the M10x80mm ID.2 screws into it.
3. Insert this whole assembly into the motorcycle frame and pull it down from the back with the M10 ID.3 nuts.
4. Now take the ID.4 plastic caps and put them on the screw heads that are in the duralumin adapter on the motorcycle frame.
5. Mount the duralumin adapter on the opposite side using the same procedure.
6. Now take the M10x35mm ID.6 bolt and insert it into the duralumin roller under the ID.5 slider, mount this whole assembly into the prepared thread in the duralumin adapter on the motorcycle.
7. Using the same procedure, mount the duralumin roller under the slider on the opposite side as well.
8. Take the slider and M6x25mm ID.7 screws and mount it on the duralumin roller on the motorcycle. Then mount the aluminum cap in the slider with M4x12mm ID.8 screws.

Notice:

We recommend using medium strength thread glue.

