

A5SDM

Aprilia SL750 Shiver
Aprilia SMV750 Dorsoduro
Aprilia Dorsoduro 1200

Kit for the left side

ID.	Description	Cat.no.	pcs
1	Dural. cylinder 30mm	171	1
2	Dural. cylinder 61mm	31	1
3	Bolt M6x20	1024	2
4	Washer M6	1023	2
5	nut M12	811	1
6	Slider adapter	537B	1

Kit for the right side

ID.	Description	Cat.no.	pcs
1	Dural. cylinder 30mm	171	1
2	Dural. cylinder 61mm	31	1
3	Bolt M6x20	1024	2
4	Washer M6	1023	2
5	nut M12	811	1
6	Slider adapter	537B	1

7	Stainless steel rod M12x485X30X30	1
---	--	---

Instructions:

1. Remove original bolt M12 from frame of motorcycle.
2. Insert steel rod (ID7) into frame of motorcycle.
3. Put dural cylinders (ID1+ID2) on both ends of steel rod.
4. Now mount slider adapter (ID6) on dural. cylinder and tighten them using M12 nut (ID5).
5. Fit slider on the slider adapter (ID6) using two M6 bolts (ID3) and washers (ID4).

We recommend to use the glue on all threads (medium strong – blue colour).

