



# B10

## BMW S1000RR 2015-

### Mounting kit:

ID.	Description	Cat.no.	pcs
1	Steel insert	X1	2
2	Bolt M10x80 mm	852	1
3	Alu. spacer d=10 mm	287	2
4	Alu. spacer d=30 mm	3	1
5	Bolt M10x110 mm	879	1

### Instructions for the right side:

1. Insert Bolt (ID2) and steel insert (ID1) into the protector.
2. Place spacer (ID3) on the bolt.
3. Fit this set on the right side of the motorcycle according to the picture below.

### Instructions for the left side:

1. Insert bolt (ID2) and steel insert (ID1) into the protector.
2. Place spacers (ID4 + ID3) on the bolt.
3. Fit this set on the left side of the motorcycle according to the picture below.

**We recommend to use the glue on all threads.**

