

H3SD

Honda CB900F Hornet 2002-

Kit for the left side

No.	Description	Cat.No.	Pcs
1	SLD adapter	537	1
2	Bolt M10x85mm	981	1
3	Dural. cylinder 30mm	3	1
4	Spring Washer M10	801	1
5	Bolt M8x25	815	2
6	Washer M8	800	2
7	Dural. adapter (cylinder)	10	1

Kit for the right side

No.	Description	Cat.No.	Pcs
1	SLD adapter	537	1
2	Bolt M10x85mm	981	1
3	Dural. cylinder 30mm	3	1
4	Spring Washer M10	801	1
5	Bolt M8x25	815	2
6	Washer M8	800	2
7	Dural. adapter (cylinder)	10	1



Instructions

- 1) Unbolt original bolt from the frame of motorcycle.
- 2) Put washer ID4, SLD adapter ID1, dural cylinder ID3 and cylinder adapter ID7 on bolt ID2.
- 3) Mount this kit into the frame of motorcycle.
- 4) Fit slider on the SLD adapter using two bolts ID5 and washers ID6.

We recommend to use medium strong glue on all threads.

