



H30

Honda VFR1200 F/DCT 2010-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M12x120x1,25mm	913	1
3	Duralumin cylinder d=15mm	121	1
4	Duralumin cylinder d=40mm	4	1
5	Bolt M10x75mm	1007	1
6	Duralumin adapter	629	1
7	Tape 3M		1
8	Hexagon 10mm, lenght 23mm	X41	1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M12x80x1,25mm	908	1
3	Dural. cylinder d=15mm	121	1
4	Dural. cylinder d=50mm	5	1
5	Bolt M10x85mm	981	1
6	Duralumin adapter	630	1
7	Tape 3M		1

Installation – the left side:

1. remove the original side plastic and the bolt M12 in the frame of the motorcycle
2. use the tape 3M (No. 7) in the place of installation
3. take the bolt (No. 2) and give this bolt into the duralumin adapter (No. 6), the other side give duralumin cylinder (No. 3) on this bolt, all this set mount on the frame of the motorcycle
4. screw up and mount the side plastic back
5. give the bolt (No. 5) together with steel box (No. 1) into the protector, the other side of protector give duralumin cylinder (No. 4) on the bolt
6. all this set mount on adapter

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

Installation – the right side:

1. remove the original side plastic and the bolt M12 in the frame of the motorcycle
2. use the tape 3M (No. 7) in the place of installation
3. take the bolt (No. 2) and give this bolt into the duralumin adapter (No. 6), the other side give duralumin cylinder (No. 3) on this bolt, all this set mount on the frame of the motorcycle
4. screw up and mount the side plastic back
5. give the bolt (No. 5) together with steel box (No. 1) into the protector, the other side of protector give duralumin cylinder (No. 4) on the bolt
6. all this set mount on adapter

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

ILLUSTRATIVE PHOTO OF THE PLACE OF INTALLATION





RDMOTO CZECH REPUBLIC
info@rdmoto.cz
www.rdmoto.cz

