

CF44

Moto Guzzi V7

Fitting kit:

ID	Description	Cat.N	Qt
1	Bolt M10x60	850	2
2	Bolt M8x20	824	2
3	Bolt M6x16	962	2
4	Washer M6	947	2
5	Washer M8	802	2
6	Plastic cap	X19	2
7	RDmoto stickers	-	2
8	Cover plate	X87	1



1. Dismantle original bolts from chassi.
2. Tighten bolt ID.1 slightly
3. After fix upper frames tighten all bolts and place plastic caps.





1. Connect upper crash bars.
2. Tighten slightly M8 ID.2. Place washers under the bolts ID.5.
3. Steel cover assembly on the crash bar. Use bolts. Place washers ID.4.
4. Now tighten all bolts.

During assembly use medium strong adhesive glue.