

K49SD

Kawasaki Z900RS 2017-

Left side kit:

ID	Description	Cat.no	Pcs
1	SLD adapter	537	1
2	Dural. adapter	10	1
3	Dural. cylinder	145	1
4	Bolt M10x135x1,25	930	1
5	Washer M8	800	2
6	Bolt M8x25	815	2

Right side kit:

ID	Description	Cat.no.	Pcs
1	SLD adapter	537	1
2	Dural. adapter	10	1
3	Dural. cylinder	145	1
4	Bolt M10x135x1,25	930	1
5	Washer M8	800	2
6	Bolt M8x25	815	2

Instructions:

- 1.) Uscrew original bolt from the frame.
- 2.) Put SLD adapter, dural. adapter and dural. cylinder on the bolt M10.
- 3.) Mount this kit on the frame of motorcycle.
- 4.) Mount slider on the SLD adapter using two bolts and washers M8.

We recommend to use the glue on all threads.



