

S25S

Suzuki DL650/1000 V- Strom

LEFT SIDE KIT

ID	Description	Cat.no.	Pcs
1	Slider adapter	314	1
2	Steel nut M12	X12	1
3	Dural cylinder 30mm	DV170	1
4	M6x25	877	3
5	M4x16	876	2
4	Rod M12x405x1,25mm		1

RIGHT SIDE KIT

ID	Description	Cat.no.	Pcs
1	Slider adapter	314	1
2	Steel nut M12	X12	1
3	Dural cylinder 30mm	DV170	1
4	M6x25	877	3
5	M4x16	876	2

INSTRUCTIONS

- 1) Unbolt original bolt M12 from the motorcycle.
- 2) Put steel rod through the frame.
- 3) Put dural cylinders ID3 and slider adapters ID1 on the both ends of the rod.
- 4) Tighten all using nuts M12 ID2.
- 5) Fit slider using three bolts M6.
- 6) Fit cover using two bolts M4.

We recommend to use safety glue on all threads.

