

Y1

Yamaha YZF 600 ThunderCat '96-

Kit for left side:

ID	Description	Cat.N	QTY
1	Steel bush	X1	1
2	Alu.spacer L=30mm	164	1
3	M10x95x1,25	927	1

Kit for right side:

ID	Description	Cat.N	QTY
1	Steel bush	X1	1
2	Alu.spacer L=41mm	165	1
3	M10x110x1,25	928	1

Instruction for left side:

1. Take off original bolt M10 from frame.
2. Insert ID. into the protector.
3. Under the protector place alu. spacer ID.2. This kit mount on the frame and tighten it by bolt ID.3

Instruction for right side:

1. Take off original bolt M10 from frame.
2. Insert ID. into the protector.
3. Under the protector place alu. spacer ID.2. This kit mount on the frame and tighten it by bolt ID.3

We recomanded use glue on threads. Medium strong.

