

Y14SD

Yamaha FZ-1 2006-

Kit for the left side

No.	Description	Cat.no	Pcs
1	SLD adapter	537	1
2	Bolt M10x100x1,25mm	892	1
3	Dural. cylinder d=32mm	55	1
4	Dural. cylinder (adapter)	10	1
5	Spring washer M10	801	1
6	Bolt M8x25	815	2
7	Washer M8	800	2

Kit for the right side

No.	Description	Cat.no	Pcs
1	SLD adapter	537	1
2	Bolt M10x100x1,25mm	892	1
3	Dural. cylinder d=32mm	55	1
4	Dural. cylinder (adapter)	10	1
5	Spring washer M10	801	1
6	Bolt M8x25	815	2
7	Washer M8	800	2



INSTRUCTIONS

- 1) **We recommend to use medium strong glue on all threads.**
- 2) Unbolt original bolt M10 from the frame of motorcycle.
- 3) Put washer ID5, SLD adapter ID1, cylinder ID3 and cylinder adapter ID4 on bolt ID2.
- 4) Mount this kit into the frame of motorcycle.
- 5) Fit slider using two bolts ID6 and washers ID7.

