

Y15S

Yamaha R6 2006-2011

Kit for the left side:

ID	Description	Cat.N.	Qt.
1	Dural.adapter for SL01	315	1
2	Bolt M10x60x1,25	896	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2
5	Bolt M10x40	854	1
6	Dural.spacer d=10mm	108	1
7	Steel adapter	579	1
8	Washer M10	804	1
9	Nut M10-lock	810	1
10	Plastic cover	X4	1
11	3M Tape	3M	1

Kit for the right side:

ID	Description	Cat.N.	Qt.
1	Dural.adapter for SL01	311	1
2	Bolt M10x60x1,25	896	1
3	Bolt M6x25	877	3
4	Bolt M4x16	876	2

Installation – the left side:

1. Take off fairing from the bike.
2. Remove the original bolt M10 from frame.
3. Use the bolt ID.2 for mounting of the steel adapter ID.7. Give the duralumin spacer ID.6 on the bolt during installation. Stick the 3M tape ID.11 on the frame of the motorcycle at the point of touching frame with steel adapter.
4. Give the plastic cover ID.10 into the head of screw.
5. If you mounted duralumin adapter, you can mount gripping for slider. Use bolt with pad (ID.5 and ID.8) and nut (ID.9) for mounting of duralumin adapter ID.1 on the steel adapter. Check the photo for right position of slider.
6. Screws ID.3 mounting slider on the dural. adapter. Insert alu. cover into the slider and tighten it by bolt ID.4
7. Put fairing on.

Installation – the right side:

1. Take off fairing from the bike.
2. Remove the original bolt M10.
3. Use the bolt ID.2 for gripping of duralumin cylinder ID.1 Check the photo for right position of slider.
4. Screws ID.3 mounting slider on the dural. adapter. Insert alu. cover into the slider and tighten it by bolt ID.4
5. Put fairing on.

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

