

Y28

Yamaha XJ6 Diversion F 2010-

Kit for the left side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x50x1,25mm	921	1
3	Bolt M10x35mm	847	1
4	Duralumin adapter	615	1
5	Tape 3M		1

Kit for the right side

No.	Description	Cat.no.	Pcs
1	Steel box M10	X1	1
2	Bolt M10x50x1,25mm	921	1
3	Bolt M10x30mm	882	1
4	Duralumin adapter	616	1
5	Tape 3M		1



Installation – the left side:

1. remove the original side plastic and the bolt M10 in the frame of the motorcycle
2. use the tape 3M (No. 5) on the frame of the motorcycle in the place of the installation
3. use the bolt (No. 2) for tightening of the adapter (No. 4) to the frame of the motorcycle
4. give the steel box (No. 1) together with the bolt (No. 3) into the protector
5. all this set you can mount into the adapter

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

Installation – the right side:

1. remove the original side plastic and the bolt M10 in the frame of the motorcycle
2. use the tape 3M (No. 5) on the frame of the motorcycle in the place of the installation
3. use the bolt (No. 2) for tightening of the adapter (No. 4) to the frame of the motorcycle
4. give the steel box (No. 1) together with the bolt (No. 3) into the protector
5. all this set you can mount into the adapter

Warning – we recommend to use safety glue on threads of all bolts (moderate strong – blue colour).

ILLUSTRATIVE PHOTOS OF PLACE OF THE INSTALLATION

