

# Y36SDM

## Yamaha R1 2015

### Kit for left side:

ID	Description	Cat.N	QTY
1	Dural.bracket for SLD	537/B	1
2	Bolt M12x110x1,25	910	1
3	Alu.spacer d=60mm	152	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2

### Kit for right side:

ID	Description	Cat.N	QTY
1	Dural.bracket for SLD	537/B	1
2	Bolt M12x90x1,25	931	1
3	Alu. spacer d=35mm	153	1
4	Bolt M6x20	1024	2
5	Washer M6	1023	2
6	Dural. roller d=5mm	1260	1

### Instruction to assembly:

1. The first do assembly left side.
2. Please leave all spacer´s/bushes in place.
3. Take the dural. bracket ID.1 for **left side**, insert bolt ID.2 through the bracket and aluminum spacer ID.3.
4. This kit gripping on the frame.
5. Place slider and for tighten take bolts ID.4 and washers ID.5
6. **Mounting instruction for right side.**
7. Please leave all spacer´s/bushes in place.
8. Take the dural. bracket ID.1, insert bolt ID.2 through the bracket and aluminum spacer ID.3.
9. Gripping it on the frame.
10. Place slider and for tighten take bolts ID.4 and washers ID.5
11. For the right position and assembly check the pictures.

**Warning: We recommend use the glue of all threads. Medium strong.**



